

Client: American Mold Experts
C/O: Mr Bill Nicoll, cmi
Re: Stephanie H., Pre TestDate of Sampling: 10-28-2019
Date of Receipt: 10-29-2019
Date of Report: 10-29-2019**SPORE TRAP REPORT: NON-VIABLE METHODOLOGY**

Location:	A1: Basement			A2: Bedroom 1		
Comments (see below)	A			None		
Lab ID-Version‡:	10866042-1			10866043-1		
Analysis Date:	10/29/2019			10/29/2019		
	raw ct.	% read	spores/m3	raw ct.	% read	spores/m3
Alternaria	1	100	13			
Ascospores	6	25	320			
Basidiospores	69	25	3,700	30	25	1,600
Chaetomium	1	100	13			
Cladosporium	36	25	1,900	9	25	480
Epicoccum	4	100	53			
Fusarium						
Myrothecium						
Nigrospora						
Other colorless						
Penicillium/Aspergillus types†	477	25	25,000	102	25	5,400
Pithomyces	1	100	13	1	100	13
Rusts	1	100	13	3	100	40
Smuts, Periconia, Myxomycetes	10	100	130	1	100	13
Stachybotrys						
Stemphylium						
Torula						
Ulocladium						
Zygomycetes						
Background debris (1-4+)††	4+			3+		
Hyphal fragments/m3	310			53		
Pollen/m3	< 13			< 13		
Skin cells (1-4+)	< 1+			1+		
Sample volume (liters)	75			75		
§ TOTAL SPORES/m3			32,000			7,600

Comments: A) Trace overloaded with debris. The counts provided should be considered as minimal.

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

† The spores of *Aspergillus* and *Penicillium* (and others such as *Acremonium*, *Paecilomyces*) are small and round with very few distinguishing characteristics. They cannot be differentiated by non-viable sampling methods. Also, some species with very small spores are easily missed, and may be undercounted.

†† Background debris indicates the amount of non-biological particulate matter present on the trace (dust in the air) and the resulting visibility for the analyst. It is rated from 1+ (low) to 4+ (high). Counts from areas with 4+ background debris should be regarded as minimal counts and may be higher than reported. It is important to account for samples volumes when evaluating dust levels.

The analytical sensitivity is the spores/m³ divided by the raw count, expressed in spores/m³. The limit of detection is the analytical sensitivity (in spores/m³) multiplied by the sample volume (in liters) divided by 1000 liters.

For more information regarding analytical sensitivity, please contact QA by calling the laboratory.

‡ A "Version" indicated by -"x" after the Lab ID# with a value greater than 1 indicates a sample with amended data. The revision number is reflected by the value of "x".

§ Total Spores/m³ has been rounded to two significant figures to reflect analytical precision.

Client: American Mold Experts
 C/O: Mr Bill Nicoll, cmi
 Re: Stephanie H.; Pre Test

Date of Sampling: 10-28-2019
 Date of Receipt: 10-29-2019
 Date of Report: 10-29-2019

DIRECT MICROSCOPIC EXAMINATION REPORT

Background Debris and/or Description	Miscellaneous Spores Present*	MOLD GROWTH: Molds seen with underlying mycelial and/or sporulating structures†	Other Comments††	General Impression
Lab ID-Version‡: 10866041-1, Analysis Date: 10/29/2019: Swab sample S1: Desk Leg				
Scant	Very few	None	Very few <i>Penicillium/Aspergillus</i> group spores detected.	Normal trapping

* Indicative of normal conditions, i.e. seen on surfaces everywhere. Includes basidiospores (mushroom spores), myxomycetes, plant pathogens such as ascospores, rusts and smuts, and a mix of saprophytic genera with no particular spore type predominating. Distribution of spore types seen mirrors that usually seen outdoors.

† Quantities of molds seen growing are listed in the MOLD GROWTH column and are graded <1+ to 4+, with 4+ denoting the highest numbers.

†† Some comments may refer to the following: Most surfaces collect a mix of spores which are normally present in the outdoor environment. At times it is possible to note a skewing of the distribution of spore types, and also to note "marker" genera which may indicate indoor mold growth. Marker genera are those spore types which are present normally in very small numbers, but which multiply indoors when conditions are favorable for growth.

‡ A "Version" indicated by -"x" after the Lab ID# with a value greater than 1 indicates a sample with amended data. The revision number is reflected by the value of "x".
 The limit of detection is < 1+ when mold growth is detected.